

Wright Products



(USE 1/8 DRILL BIT FOR ALL PILOT HOLES)

STEP 1

At desired height, fasten jamb bracket to door frame with open side 1/4" from door as shown. (See FIG. A) If more latching force is desired, jamb bracket may be moved up to 1" away from door. NOTE: moving the jamb bracket further from door nominally reduces door opening.

STEP 2

Slide hold-open washer on rod. Using short connecting pin, connect closer to jamb bracket. Hold-open washer should be positioned over lugs against tube as shown. This will give proper tension for installation. (Do not change until installation is completed.) (See FIG. B)

STEP 3

Attach door bracket to closer tube FRONT hole with long connecting pin. (See FIG. C)

With door tightly closed, hold closer and door bracket against door in level position, mark and drill two 1/8" pilot holes.

CAUTION: Do not drill through door. Fasten door bracket to door as shown with short screws. (See FIG. C)

Open door and move hold-open washer back of lugs on rod.

Closer is now ready to operate. The closing speed may be regulated by turning adjusting screw. (See FIG. D)

CONTROLLED LATCHING POWER FEATURE

Installed as directed, with the door bracket attached to the front hole of the door closer, the bypass valve built into this closer will accelerate the closing speed of the door in the last few inches of travel. This attachment position is recommended when the glass storm panel is in place.

If a smoother, more quiet closing action is desired, hold door open about 8" with hold-open washer, remove long connecting pin from door bracket and relocate in closer tube REAR hole.

This position is normally used when the screen panel is in place. (See FIG. C)

INSTALLATION INSTRUCTIONS

(Use of a little oil or soap on threads makes driving screws much easier)

THIS CLOSER MAY BE INSTALLED ON RAIL AT TOP OF DOOR OR ON MULLION STRIP NEAR CENTER. WHICHEVER IS DESIRED

NOTE: BEFORE INSTALLATION, CHECK DOOR TO SEE THAT IT CLOSSES FREELY"

